


## MODEL 35 - WEDGEWOOD (RV / CV), ATWOOD (RA / CA) Oven & Slide-In Cooktop Parts Identification



Item	Description	WEDGEWOOD			ATWOOD		
		RV		CV	RA		CA
		1735	2135	35	1735	2135	35
1	Grate - black	56272	56272	56272	57190	57190	57190
2A	Grommet	53009	53009	53009	53009	53009	53009
2B	Sealed Grate U-Channel				57194	57194	57194
3	Top Spring Clip	51035	51035	51035	51035	51035	51035
4	Range Top - white, side latches	52014	52014	52014	52753	52753	52753
	Range Top - black, side latches	52015	52015	52015	52752	52752	52752
	Range Top - stainless steel, side latches	57532	57532	57532	52754	52754	52754

Continued

5A	Kit, Burner, Sparklite – left	52717	52717	52717			
5A	Kit, Burner, Matchlit – left	52718	52718	52718			
5B	Kit, Burner, Sparklite – center	52715	52715	52715			
5B	Kit, Burner, Matchlit – center	52716	52716	52716			
5C	Kit, Burner, Sparklite – right	52713	52713	52713			
5C	Kit, Burner, Matchlit – right	52714	52714	52714			
5D	Burner head (twist lock)				52750	52750	52750
6	Bushing, Burner	53011	53011	53011	53011	53011	53011
8	Brass Fitting	52166	52166	52166	52166	52166	52166
9	Kit, gas regulator	51062	51062	51062	51062	51062	51062
10	Kit, manifold pipe	52712	52712	52164	52712	52712	52164
11	Bolt, mini valve/ thermostat	52168	52168	52168	52168	52168	52168
13	Kit, Valve, Burner – 9000 BTU	52711	52711	52711	52711	52711	52711
14	Kit, Valve, Burner – 6500 BTU	52710	52710	52710	52710	52710	52710
16	Kit, thermostat oven control	52709	52709		52709	52709	
17	Piezo Ignitor	56096	56096	56096	56096	56096	56096
18A	Burner tube – left rear				52749	52749	52749
18B	Burner tube – center front				52748	52748	52748
18C	Burner tube – right rear				52747	52747	52747
19	Burner tube bracket				52803	52803	52803
20	Kit, knobs (piezo, burners & oven)	52719	52719	52719	52719	52719	52719
23	Control panel label – w/o label	*	*	*	*	*	*
24	Control panel label	*	*	*	*	*	*
25	Burner box	51687	51687	51687	51687	51687	51687
27	Oven can	51969	51970		51969	51970	
28	Oven rack	51069	51069		51069	51069	
29	Oven shelf	51670	51670		51670	51670	
30	Door assembly includes handle – black steel	51977	51983		51977	51983	
30	Door assembly includes handle – white steel	51978	51984		51978	51984	
30	Door assembly includes handle – white glass	51981	51987		51981	51987	
30	Door assembly includes handle – black glass	51980	51986		51980	51986	
30	Door assembly includes handle – stainless steel	51958	51992		51958	51992	
30	Door assembly white handle – white steel	51957			51957		
	Door – glass insert – sm. black	51881			51881		
	Door – glass insert – lg. black		51882			51882	
	Door – glass insert – sm. white	51883			51883		
	Door – glass insert – lg. white		51884			51884	
31	Oven door handle - black	52025	52025		52025	52025	
	Oven door handle – white	52026	52026		52026	52026	
32	Kit, oven gas supply assembly	52704	52704		52704	52704	
33	Kit, pilot burner assembly	52706	52706		52706	52706	
34	Kit, oven burner	52705	52705		52705	52705	
35	Kit, thermocouple	52707	52707		52707	52707	
36	Oven can trim	51975	51976		51975	51976	
N/S	Kit, 3/16 pilot gas tube	52708	52708		52708	52708	
N/S	Kit, piezo ignition leads	57553	57553	57553	57553	57553	57553
N/S	Kit, oven door hinges	57557	57559		57557	57559	
N/S	Kit, door seal	51060	51061		51060	51061	

N/S = Not shown in the illustration    OBS = Obsolete    # = Order quantity needed    WSL = while supplies last    \* = Order by model, color, and style